

Size: 19" x 19"

Please Read and Save this Use and Care Book.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock and injury to persons do not immerse cord, plugs or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- To disconnect, turn any control off, then remove plug from wall outlet.
- Do not use this appliance for other than intended use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS.

This product is for household use only.

GROUNDING PLUG (220V Models Only)

As a safety feature, this product is equipped with a grounded plug, which will only fit into a three-prong outlet. Do not attempt to defeat this safety feature. Improper connection of the grounding conductor may result in the risk of electric shock. Consult a qualified electrician if you are in doubt as to whether the outlet is properly grounded.

TAMPER-RESISTANT SCREW

Warning: this appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

21. After 5 seconds, {{{ will stop blinking, to show the temperature is set.
22. The element will switch on intermittently, to keep the water hot.
23. After 40 minutes, the function will switch off.
24. {{{ will disappear from the display.
25. The display will show the temperature of the water in the kettle.

SWITCHING OFF

26. When the water boils the element will switch off.
27. To stop the kettle, press and release the ☞ button.
28. The display will show the temperature of the water in the kettle.
29. To save electricity, unplug the stand.
30. The appliance will remember the setting for up to 24 hours.

GENERAL

31. When you lift the kettle, you may see moisture on the stand. Don't worry – it's the steam used to switch off automatically, which then condenses and escapes via vents under the kettle.
32. You may see some discoloration on the floor of the kettle. Again, don't worry – it's due to the bonding of the element to the kettle floor.
33. If you normally heat water to less than 100°C, and keep it warm, you may ignore the ☞ button, and use the keep warm function on its own.

USING WITH INSUFFICIENT WATER

34. This will shorten the life of the element. A boil-dry cut-out will switch the kettle off.
35. You must then remove the kettle from its stand to reset the cut-out.
36. Sit the kettle on the work surface till it's cold.

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

37. Unplug the stand from the wall socket, and let the kettle cool down fully before cleaning.
38. Wipe all surfaces with a clean damp cloth.
39. Keep the connectors dry.

CLEANING THE FILTER

40. Switch the kettle off, and let it cool.
41. Open the lid.
42. Grip the top of the filter, and push it down and into the kettle to release it.
43. Lift or tip it out of the kettle.
44. Rinse the filter under a running tap while brushing with a soft brush.

REPLACE THE FILTER

45. Fit the bottom of the filter into the mount at the bottom of the spout.
46. Push the top of the filter towards the spout, to force the top hooks under the rim of the kettle.

DESCALE REGULARLY

ELECTRICAL CORD

- a) A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b) Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c) If a long detachable power-supply cord or extension cord is used,
 - 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance,
 - 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Note: If the power supply cord is damaged, it should be replaced by qualified personnel; in Latin America by an authorized service center.

Beverages	Water Temperature °C	Brewing Time (Min)
Mate	75 – 90	3 – 5
black tea	80 – 90	5 – 7
whole leaf black tea	85 – 90	4
broken leaf black tea	85 – 90	5
smoked tea	85 – 90	3 – 4
flavoured black tea	85	3 – 4
green tea	60 – 95	2 – 5
flavoured green tea	60 – 75	3 – 4
Gyokuro (Japanese tea)	50 – 55	1
Sencha (Japanese green tea)	65 – 70	45 seconds to 1 minute (2.5g tea per 100ml water) or 2 minutes (3.5g tea per 100ml water)
Genmaicha (Japanese green tea)	90 – 95	2 – 3
wu long/oolong/blue/blue-green	80 – 95	about 7 minutes
yellow tea	70 – 75	2 – 4
white tea	70 – 85	7 to 20 minutes (4 to 5 infusions possible)
instant coffee	75	
coffee (piston/plunger coffee pot)	95	

47. Descalcify the appliance at least monthly with a proprietary descaler. Follow the instructions the package of the descaler.

CORD STORAGE

Conveniently store the cord beneath swivel base by wrapping it around grooves on the base.

¿NECESITA AYUDA?

Para servicio, reparaciones o preguntas relacionadas al producto, por favor llame al número del centro de servicio que se indica para el país donde usted compró su producto.

NO devuélva el producto al fabricante. Llame o lleve el producto a un centro de servicio autorizado.

DOS AÑOS DE GARANTÍA LIMITADA

(No aplica en México, Estados Unidos y Canada)

¿Qué cubre la garantía?

- La garantía cubre cualquier defecto de materiales o de mano de obra que no haya sido generado por el uso incorrecto del producto.

¿Por cuánto tiempo es válida la garantía?

- Por dos años a partir de la fecha original de compra mientras que tenga una prueba de la compra.

¿Cómo se obtiene el servicio necesario?

- Conserve el recibo original como comprobante de la fecha de compra, comuníquese con el centro de servicio de su país y haga efectiva su garantía si cumple lo indicado en el manual de instrucciones.

¿Cómo se puede obtener servicio?

- Conserve el recibo original de compra.
- Por favor llame al número del centro de servicio autorizado.

¿Qué aspectos no cubre esta garantía?

- Los productos que han sido utilizados en condiciones distintas a las normales.
- Los daños ocasionados por el mal uso, el abuso o negligencia.
- Los productos que han sido alterados de alguna manera.
- Los daños ocasionados por el uso comercial del producto.
- Los productos utilizados o reparados fuera del país original de compra.
- Las piezas de vidrio y demás accesorios empacados con el aparato.
- Los gastos de tramitación y embarque asociados al reemplazo del producto.
- Los daños y perjuicios indirectos o incidentales.

¿Qué relación tiene la ley estatal con esta garantía?

- Esta garantía le otorga derechos legales específicos y el consumidor podría tener otros derechos que varían de una región a otra.

Product may vary slightly from what is illustrated.



1. Anti-drip pour spout
2. Removable filter
3. Lid release lever
4. Stay-open hinged lid
5. Handle
6. Digital display
7. Buttons for functions
8. Base

How to Use

This product is for household use only.

GETTING STARTED

- Remove all packing material and any stickers from the product.
- Remove and save literature.
- Wash all parts as instructed in Care and Cleaning section.
- Select a level surface where this unit is to be used allowing enough space for steam to escape without damage to counters, cabinets and walls.

Póliza de Garantía

(Válida sólo para México)

Duración

Spectrum Brands de México SA de CV garantiza este producto por 2 años a partir de la fecha original de compra.

¿Qué cubre esta garantía?

Esta Garantía cubre cualquier defecto que presenten las piezas, componentes y la mano de obra contenidas en este producto.

Requisitos para hacer válida la garantía

Para reclamar su Garantía deberá presentar al Centro de Servicio Autorizado la póliza sellada por el establecimiento en donde adquirió el producto. Si no la tiene, podrá presentar el comprobante de compra original.

¿Dónde hago válida la garantía?

Llame sin costo al teléfono 01 800 714 2503, para ubicar el Centro de Servicio Autorizado más cercano a su domicilio en donde usted podrá encontrar partes, componentes, consumibles y accesorios.

Procedimiento para hacer válida la garantía

Acuda al Centro de Servicio Autorizado con el producto con la póliza de Garantía sellada o el comprobante de compra original, ahí se reemplazará cualquier pieza o componente defectuoso sin cargo alguno para el usuario final. Esta Garantía incluye los gastos de transportación que se deriven de su cumplimiento.

Excepciones

Esta Garantía no será válida cuando el producto:

- A) Se hubiese utilizado en condiciones distintas a las normales.
- B) No hubiese sido operado de acuerdo con el instructivo de uso que le acompaña.
- C) Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por Spectrum Brands de México SA de CV.

Nota: Usted podrá encontrar partes, componentes, consumibles y accesorios en los centros de servicios autorizados. Esta garantía incluyen los gastos de transportación que se deriven de sus cumplimiento dentro de sus red de servicio.

- Fill kettle with 4 cups (32 oz.) cold tap water and bring to a boil. Add 2 cups (16 oz.) white vinegar, let stand for at least 1 hour or overnight and discard.
- Fill kettle to maximum fill line with cold tap water. Bring to boil, discard and repeat. Kettle is now ready for use.

FILLING

1. Squeeze the lid lock into the lid to open it.
2. Fill with at least 2 cups of water, but not above max.
3. Close the lid, and press down to lock it.

Important:

- Do not operate kettle without water.
- Do not operate kettle without removable filter in place.
- Do not overfill kettle and keep water level below the maximum mark on the water window.
- Keep the lid closed while water is heating.

SWITCHING ON

4. Put the stand on a stable, level surface.
5. Plug the stand into the wall socket.
6. Put the kettle on the stand.
7. The display will show the temperature of the water in the kettle.
8. Press and release the ☞ button.
9. 100°C will show on the display.
10. ☞ will blink on the display.

BOIL

11. If you want to boil the water, do nothing.

VARIABLE TEMPERATURE

12. Use the ▲ and ▼ buttons to set the temperature.
13. The temperatures available are: 100°C (boil), 95°C, 90°C, 85°C, 80°C, 75°C, 70°C, 65°C, 60°C, 55°C, 50°C, 45°C, 40°C, 35°C, 30°C, and 25°C.
14. After 5 seconds, ☞ will stop blinking, to show the temperature is set.
15. When the water reaches the temperature you set:
 - a) ☞ will disappear from the display.
 - b) The display will show the temperature of the water in the kettle.

KEEP WARM – 40 MINUTES

16. If you have chosen a temperature below 100°C, and you want to keep the water warm:
 17. Press and release the {{{ button.
 18. {{{ will blink on the display.
 19. Use the ▲ and ▼ buttons to set the temperature.
 20. This function only works at the 95°C, 90°C, 85°C, 80°C, 75°C, 70°C, 65°C, 60°C, 55°C, 50°C, 45°C, 40°C, 35°C, 30°C, and 25°C settings.

Por favor llame al número correspondiente que aparece en la lista a continuación para solicitar que se haga efectiva la garantía y donde puede solicitar servicio, reparaciones o partes en el país donde el producto fué comprado.

Argentina

Atención al consumidor
0800 444 7296
Horario de atención: Lunes a viernes de 9 a 13 hs y de 14.30 a 17 hs.
Mail: servicios@rayovac.com.ar
Humboldt 2495 piso 3
C.A.B.A. – Argentina

Chile

SERVICIO DE MAQUINAS Y
HERRAMIENTAS LTDA.
Portugal Nº 644
Santiago – Chile
Fonos: 02-6355208 / 02-6341169
Email: servicio@spectrumbrands.cl
Call center: 800-171-051

Colombia

Rayovac Varta S.A
Carrera 17 Número 89-40
Línea gratuita nacional
018000510012

Costa Rica

Aplicaciones Electromecánicas
Calle 22 y 24 en Avenida 3 BLV de la torre Mercedes
Benz
200 mts norte y 50 mts este
San José, Costa Rica
Tel. (506) 2257-5716

Ecuador

Servicio Master
Dirección: Capitán Rafael
Ramos OE 1-85 y Galo plaza laso.
Tel (593) 2281-3882 / 2240-9870

El Salvador

Sedeblack
Calle San Antonio Abad, Colonia Lisboa No 2936
San Salvador, Depto. de San Salvador
Tel. (503) 2284-8374

Guatemala

Kinal
17 avenida 26-75, zona 11 Centro comercial
Novicentro,
Local 37 - Ciudad
Guatemala
Tel. (502)-2476-7367

Honduras

Serviteca
San Pedro Sula, B Los Andes, 2 calle -entre 11-12
Avenida
Honduras
Tel. (504) 2550-1074

México

Artículo 123 # 95 Local 109 y 112
Col. Centro, Cuauhtemoc,
México, D.F.
Tel. 01 800 714 2503

Nicaragua

LRM ELECTRONICA
Managua - Sinsa Altamira 1.5 kilómetros al norte
Nicaragua
Tel. (505) 2270-2684

Panamá

Supermarcas
Centro comercial El dorado, Plaza Dorado, Local 2.
Panama
Tel. (507) 392-6231

Perú

Servicio Central Fast Service
Av. Angamos Este 2431
San Borja, Lima Perú
Tel. (511) 2251-388

Puerto Rico

Buckeye Service
Jesús P. Piñero #1013
Puerto Nuevo, SJ PR 00920
Tel.: (787) 782-6175

República Dominicana

Prolongación Av. Rómulo
Betancourt
Zona Industrial de Herrera
Santo Domingo, República
Dominicana
Tel.: (809) 530-5409

Venezuela

Inversiones BDR CA
Av. Casanova C.C.
City Market Nivel Plaza Local 153
Diagonal Hotel Melia, Caracas.
Tel. (582) 324-0969